

Remapped Channel Installation

*	1	Ls	AZI	-120.0	ELEV	0.0	
	2	Rs	AZI	120.0	ELEV	0.0	
	3	Lb	AZI	-150.0	ELEV	0.0	
	4	Rb	AZI	150.0	ELEV	0.0	
*	5	Lrs1	AZI	-120.0	ELEV	0.0	
	6	Rrs1	AZI	120.0	ELEV	0.0	
	7		AZI	0.0	ELEV	0.0	
	8		AZI	0.0	ELEV	0.0	↓

* To be used for 5.1 or 5.1.X Listening Rooms
* To be used for 7.1 or larger Listening Rooms

First, you will need to click the “Listening Rooms” on the main menu.

The screenshot shows a main menu with the following items:

- Presets A John HDMI !
- Presets B User 2 Disabled
- Audio Source HDMI 1
- Listening Rooms
- Apps
- Files
- Settings

Then Update the “Surrounds” to “must match”

The screenshot shows the Surrounds settings menu with the following text:

Loading only Atmos

Surrounds


Install Remapped Channels in a 5.1 or 5.1.X Listening Room.

In order to use the remapped channels correctly, they must be loaded into an existing 5.1 or 5.1.X Listening Room.


- It is recommended to use the option to “Select all matching speakers” to first populate a 5.1 or 5.1.X Listening Room with your favorite PRIR... then load/overwrite the individual remapped channels using the “Select all matching speakers” option.
1. Once the default channels have been imported... select the Ls (Ls and Rs should be empty) channel (press enter) to load/overwrite the missing Ls and Rs channels with the newly remapped channels.



2. Select the appropriate speaker brand Remap PRIR and “Select all matching speakers”



3. Note the angle of $\pm 120^\circ$



4. Press back on the remote to save the Listening Room.

With this change, you will now experience the best possible sound immersion from 5.1 audio.


Install Remapped Channels in a 7.1 or larger Listening Room.

In order to use the remapped channels correctly, they must be individually loaded into a 7.1 or larger Listening Room.

- It is recommended to use the option to “Select all matching speakers” to first populate a 7.1 or larger Listening Room with your favorite PRIR... then load/overwrite the individual remapped channels using the “Select all matching speakers” option.
1. Once the default channels have been imported... Select the Lb channel (press enter) to load/overwrite the Listening Room with the newly remapped channels.



2. Select the appropriate speaker brand Remap PRIR and “Select all matching speakers”




3. Once completed... Note the Lb and Rb angle changes from $\pm 120^\circ$ to $\pm 150^\circ$

Default




Remapped





4. As well as the Lrs1 and Rrs1 angle changes from $\pm 110^\circ$ to $\pm 120^\circ$

Default



Remapped

21	Lrs1	Lrs1	0	3DSound	Genelec	-120	0	
22	Rrs1	Rrs1	0	3DSound	Genelec	120	0	

5. Press back on the remote to save the Listening Room.

With this change, you will now experience the best possible sound immersion from 7.1 audio.